

M-SERIES DELUXE SEAT



Tools Required
Phillips screwdriver
Allen key (supplied)



Attaching the mount to your trolley

- 1** | With your trolley folded, release CATCH 2 and unfold the upper frame section slightly so that the trolley can still rest on the handle (fig. 1-1) and resecure CATCH 2
- 2** | Release CATCH 1 and unfold the front wheel fully until it locks into position (fig. 1-2)
- 3** | Place the larger section of the mount on top of the lower frame tubes as close as possible to the front wheel housing (fig. 2) with the arrow inside pointing towards the front wheel
- 4** | Position the smaller section of the mount underneath with the arrow also pointing towards the front wheel and secure the two sections using the 6 screws (fig. 3)



Assembling and Fitting the seat

- 5** | The main section of the seat will arrive in two parts. Attach the padded seat top to the twin tubed section. Insert the nuts and bolts in position and secure using the Allen key provided (fig. 4)
- 6** | Slide the seat bar into the mount (fig. 5)
- 7** | Insert the plastic bolt into the hole on top of the mount and tighten to secure (fig. 5 inset)
- 8** | Slot the legs of the seat into the end of the seat bar (fig. 6)

